

F28HS Hardware-Software Interface: Systems Programming

Hans-Wolfgang Loidl

School of Mathematical and Computer Sciences,
Heriot-Watt University, Edinburgh



Semester 2 — 2018/19

⁰No proprietary software has been used in producing these slides



Tutorial 5: Programming an LCD Display

This tutorial will focus on programming a simple output device:
an 16x2 LCD display using an Hitachi HD44780U controller

This will be an exercise of controlling a device slightly more
complicated than the LED and button devices so far.
The principles of programming are the same as before.

We will cover:

- ① Connecting an LCD display to the RPi2
- ② Low-level interface in assembler (`digitalWrite`)
- ③ Medium-level interface in C (`lcdClear` etc)
- ④ Sending characters and strings (`lcdPutChar`, `lcdPuts`)
- ⑤ Character data (defining own characters)

Overview



Acknowledgements


The code in this tutorial is mostly taken directly from the [wiringPi](#) library for the Raspberry Pi, by [Gordon Henderson](#).
If you have downloaded the sources, you can look-up examples in the directory `wiringPi/examples` (e.g. `lcd.c`) and the code for the LCD functions in `wiringPi/devLib` (also `lcd.c`)

```
* wiringPi:  
* Arduino look-a-like Wiring library for the Raspberry Pi  
* Copyright (c) 2012-2015 Gordon Henderson  
* Additional code for pwmSetClock by Chris Hall <chris@kchall.plus.com>  
*  
* Thanks to code samples from Gert Jan van Loo and the  
* BCM2835 ARM Peripherals manual, however it's missing  
* the clock section /grr/mutter/  
*****  
* This file is part of wiringPi:  
* https://projects.drogon.net/raspberry-pi/wiringpi/
```



Function dependencies

Here is a simple picture of the dependencies of the API functions:



NB: only the lowest level, `digitalWrite` is in assembler, the rest is in C




LCD commands

We need some constant definitions and boilerplate code:

Here is a list of instructions for the Hitachi HD44780U controller:

```
#define LCD_CLEAR      0x01  
#define LCD_HOME       0x02  
#define LCD_ENTRY      0x04  
#define LCD_CTRL       0x08  
#define LCD_CDSHIFT    0x10  
#define LCD_FUNC       0x20  
#define LCD_CGRAM      0x40  
#define LCD_DGRAM      0x80
```

1. The wiring



⁰See Table 6 and Figure 11 in the [HD4478 Technical Reference](#)

The wiring: encoded

To encode this wiring in the program we define:

```
#define STRB_PIN 24
#define RS_PIN 25
#define DATA0_PIN 23
#define DATA1_PIN 10
#define DATA2_PIN 27
#define DATA3_PIN 22
```



Data structure for the LCD-connection

The following data structure stores the pin numbers and cursor position:

```
struct lcdDataStruct
{
    int bits, rows, cols ;
    int rsPin, strbPin ;
    int dataPins [8] ;
    int cx, cy ;
};
```



2. Low-level Assembler interface

This code is essentially the same as in the blinking LED example, i.e. we want to “send” one bit to a pin that’s an argument to the interface:

- Set the mode of the pin to output (before calling the function)
- Identify the register and bit to write to
- Write one bit (**1**) into this location
- It is recommended that you use inline assembler to implement this function



2. Low-level Assembler interface

```
asm volatile(/* inline assembler version of setting/clearing LED to
   ouput */
"\tB\u00d7_bonzo0\n"
"_bonzo0:\u00d7NOP\n"
"\tLDR\u00d7R1,\u00d7[gpio]\n"
"\tADD\u00d7R0,\u00d7R1,\u00d7[%[off]]\n" /* R0 = GPSET/GPCLR register */
"\tMOV\u00d7R2,\u00d7#1\n"
"\tMOV\u00d7R1,\u00d7[%[pin]]\n" /* NB: this works only for pin 0-31 */
"\tAND\u00d7R1,\u00d7#31\n"
"\tLSL\u00d7R2,\u00d7R1\n"
"\tSTR\u00d7R2,\u00d7[R0,\u00d7#0]\n" /* R2 = bitmask set/clear reg %[act] */
"\tMOV\u00d7%[result],\u00d7R2\n"
: [result] "=r" (res)
: [pin] "r" (pin)
, [gpio] "m" (gpio)
, [off] "r" (off*4)
: "r0", "r1", "r2", "cc");
```



3. Medium-level interface

Sending data uses `digitalWrite` to send bits over the 4 pins:

```
void sendDataCmd (const struct lcdDataStruct *lcd, unsigned char data)
{
    unsigned char          i, d4 ;

    d4 = (myData >> 4) & 0x0F;
    for (i = 0 ; i < 4 ; ++i)
    {
        digitalWrite (lcd->dataPins [i], (d4 & 1)) ;
        d4 >>= 1 ;
    }
    strobe (lcd) ;

    d4 = myData & 0x0F ;
    for (i = 0 ; i < 4 ; ++i)
    {
        digitalWrite (lcd->dataPins [i], (d4 & 1)) ;
        d4 >>= 1 ;
    }
    strobe (lcd) ;
}
```



Sending a command

Sending a command works like sending a byte, except that we only need 4 bits to encode the command, and therefore only one loop in the body:

```
void lcdPut4Command (const struct lcdDataStruct *lcd, unsigned char
                      command) {
    register unsigned char myCommand = command ;
    register unsigned char i ;

    digitalWrite (lcd->rsPin, 0) ;

    for (i = 0 ; i < 4 ; ++i) {
        digitalWrite (lcd->dataPins [i], (myCommand & 1)) ;
        myCommand >>= 1 ;
    }
    strobe (lcd) ;
}
```



Move cursor home

Now that we can send a command, we can create instances for each of the commands that are specified for the HD44780U controller:

```
void lcdHome (struct lcdDataStruct *lcd) {
    lcdPutCommand (lcd, LCD_HOME) ;
    lcd->cx = lcd->cy = 0 ;
    delay (5) ;
}
```



4. Sending characters and strings

Sending a character involves, sending the char as a byte, moving to the next position, and updating the position on the LCD display:

```
void lcdPutchar (struct lcdDataStruct *lcd, unsigned
                  char data) {
    digitalWrite (lcd->rsPin, 1) ;
    sendDataCmd (lcd, data) ;

    if (++lcd->cx == lcd->cols) {
        lcd->cx = 0 ;
        if (++lcd->cy == lcd->rows)
            lcd->cy = 0 ;

        lcdPutCommand (lcd, lcd->cx + (LCD_DGRAM | (lcd
                                         ->cy>0 ? 0x40 : 0x00) /* rowOff [lcd->cy]
                                         */ ) ) ;
    }
}
```



Writing strings

Once we can send characters, we only need a loop on top of it to send entire strings:

```
void lcdPuts (struct lcdDataStruct *lcd, const char
    *string) {
    while (*string)
        lcdPutchar (lcd, *string++);
}
```

5. Putting things together

In the main function we:

- Memory-map the GPIO address into user space (`gpio`)
- Configure an `lcd` data structure with the pin numbers for our wiring
- Initialise the connection to this `lcd`
- Initialise the display using `lcdClear()` and `lcdHome()`
- Write “Hello World” using `lcdPuts`

See the `lcd-hello.c` sample program.

